


User manual

Instructions


Check remaining capacity.











The USB and Type-C ports can be used to charge digital devices.



The Lightning, Micro USB, Type-C ports can be used to charge the power bank.



Technical parameters

Product name	Romoss PSW30PF 30000mAh, 22.5W
Model No.	PSW30-152
Capacity	30000mAh (111Wh)
Input	 5V==2A or 9V==2A (Lightning)  5V==2A or 9V==2A (Micro USB)  5V==3A or 9V==2A (Type-C)
Output	 5V==3A or 9V==2.22A or 12V==1.67A (Type-C)  Single port: 4.5V==5A or 5V==4.5A or 9V==2A or 12V==1.5A
Total output	 +  +  =5V==3A
Size	~L171.5 x W82 x H33.6mm
Weight	~640g

Made in China



Cautions



Do not disassemble, modify, knock or strike the product.



Use only the factory supplied charging cable and power adaptor.



To extend the battery life, please use and charge the battery at least once every three months.



Never use the power bank at too high or too low temperature.



Please do not drop, press or pierce the product.



Please keep the product away from children.



Keep the product away from any liquid.

Warranty Services



12 Months of Warranty Period



Customer support is available for the period of the product life

For FAQ and more information, please visit:

www.romoss.com/support

Facebook @Romoss.official

Email: cs@romoss.com

Product Number:

Product Description: Power Bank

ACTIVATE YOUR FREE WARRANTY NOW

Register your purchased products within 5 days at:

www.romoss.com/activate



The registration will ensure your purchase under 100% warranty coverage!